

# Extraflame®

## Riscaldamento a Pellet



UK

### PELLET BOILERS USER MANUAL

**MADE IN ITALY**  
design & production

**PK 15-20-30 / PR 20-30**

## APPLY TECHNICAL DATA LABEL



## ATTENTION



**SURFACES CAN BECOME VERY HOT!  
ALWAYS USE PROTECTIVE GLOVES!**

*During combustion, thermal energy is released that significantly increases the heat of surfaces, doors, handles, controls, glass, exhaust pipes, and even the front of the appliance. Avoid contact with those elements if not wearing protective clothing (protective gloves included). Make sure children are aware of the danger and keep them away from the stove during operation.*

### ENGLISH ..... 4

<b>CHARACTERISTICS</b> .....	4
<b>INTRODUCTION</b> .....	5
<b>WARNINGS</b> .....	7
<b>SAFETY</b> .....	7
<b>ROUTINE MAINTENANCE</b> .....	9
<b>INSTALLATION</b> .....	10
<b>HYDRAULIC SYSTEM</b> .....	12
INSTALLATION AND SAFETY DEVICES .....	12
<b>ANTI-CONDENSATION DEVICE (MANDATORY)</b> .....	13
<b>IDENTIFICATION OF PR COMPONENTS</b> .....	14
<b>IDENTIFICATION OF PK COMPONENTS</b> .....	15
<b>SIDE SMOKE OUTLET PR-PK 15-20</b> .....	16
<b>SIDE SMOKE OUTLET PR-PK 30</b> .....	17
<b>BULB THERMOSTAT REACTIVATION</b> .....	18
<b>FUSE</b> .....	18
<b>FEATURES</b> .....	18
<b>TOUCH SCREEN DISPLAY</b> .....	19
<b>CONTROL BOARD</b> .....	20
ICON KEY.....	20
GENERAL MENU.....	21
GENERAL WARNINGS.....	21
<b>FIRST IGNITION SETTINGS</b> .....	22
DATE-TIME.....	22
LANGUAGE.....	22
DEGREES .....	22
<b>OPERATION AND LOGIC</b> .....	23
<b>STAND-BY - ADDITIONAL THERMOSTAT</b> .....	24
ADDITIONAL THERMOSTAT FUNCTIONING WITH STAND-BY ACTIVE .....	24
ADDITIONAL THERMOSTAT OPERATION WITH STAND-BY DEACTIVATED .....	24
ADDITIONAL THERMOSTAT INSTALLATION .....	24
<b>CHRONO</b> .....	25
ENABLING/DISABLING THE CHRONO .....	25
<b>SETTINGS</b> .....	27
DISPLAY .....	27
STAND - BY .....	27
FIRST LOAD .....	27
OUTLET AIR .....	27
Wi-Fi .....	28
RESET .....	28
<b>AUX</b> .....	28
<b>OPTIONAL ADDITIONAL BOARD (STANDARD ON PR20 AND PR30)</b> .....	28
<b>CLEANING AND MAINTENANCE</b> .....	29
<b>MAINTENANCE</b> .....	29
PERIODIC CLEANING UNDER USER'S RESPONSIBILITY .....	29
<b>CLEANING AND MAINTENANCE SUMMARY TABLE</b> .....	32
USER CLEANING .....	32
QUALIFIED TECHNICIAN .....	32
<b>ROUTINE MAINTENANCE PERFORMED BY QUALIFIED TECHNICIANS</b> .....	32
SHUT-DOWN (END OF SEASON) .....	32
<b>DISPLAYS</b> .....	34
<b>ALARMS</b> .....	34
<b>DISPOSAL</b> .....	36

CHARACTERISTICS		PK15	PK20	PK30
		-	PR20	PR30
Weight	kg	295	295(PK)/310(PR)	310(PK)/325(PR)
Height	mm	1398	1398	1398
Width	mm	822	822	892
Depth	mm	745	745 (PK)/817(PR)	745 (PK)/817(PR)
Diameter of fume outlet pipe	mm	100	100	120
Diameter of fume intake pipe	mm	60	60	60
Min global thermal input	kW	4,7	6,5	9,6
Min useful thermal input	kW	4,1	5,7	8,9
Max global thermal input	kW	16,2	21,7	32,5
Max useful thermal input (to water)	kW	15	20	30
Min fuel consumption per hour	kg/h	1,0	1,4	2,0
Max fuel consumption per hour	kg/h	3,4	4,6	6,8
Pellet hopper capacity	kg-l	75-121	75-121	75-121
Recommended flue draught	Pa	3 ÷ 5	3 ÷ 5	3 ÷ 5
	mbar	0,03 ÷ 0,05	0,03 ÷ 0,05	0,03 ÷ 0,05
Rated electrical power	W	410	410	410
Rated tension	Vac	230	230	230
Rated frequency	Hz	50	50	50
Diameter of water input/output pipe	"	1	1	1
Diameter of automatic exhaust pipe	"	1/2	1/2	1/2
Pump head	m	6	6	6
Maximum water operating pressure allowed	bar	3	3	3
Minimum water operating pressure allowed	bar	0,6	0,6	0,6
Reduced power fume temperature	°C	63,6	62	66,5
Rated power fume temperature	°C	99,8	106,6	113,8
Reduced power fume flow rate	g/s	5,1	5,8	9,1
Rated power fume flow rate	g/s	8,5	10,4	15,9
Boiler class	---	5	5	5
Combustion period	h	22	16	11
Water thermostat adjustment field	°C	65/80	65/80	65/80
Minimum water return temperature	°C	55	55	55
Direct efficiency at rated power	%	93,0	92,4	92,4
Dimensions of the feeding door	mm	306X400	306X400	306X400

		WATER FLOW (kg/h)	WATER SIDE RESISTANCE (mbar)
PK15	Temperature jump corresponding	ΔT = 10K	1300
		ΔT = 20K	650
PK20	Temperature jump corresponding	ΔT = 10K	1730
PR20		ΔT = 20K	865
PK30	Temperature jump corresponding	ΔT = 10K	2601
PR30		ΔT = 20K	1301

## INTRODUCTION

The boilers produced in our factory are built with attention to the individual components so as to protect both the user and the installer from any accidents. It is therefore recommended that after any intervention on the product, the authorised staff pay particular attention to the electric connections, especially the stripped parts of the wires. These must not escape from the terminal board in any situation, thus preventing possible contact with the live parts of the wire.

The instruction manual is an integral part of the product: make sure that it always accompanies the appliance, even if transferred to other owners or user or is transferred to another place. If it is damaged or lost, request another copy from the area technician.

This generator must be intended for the use it has been specifically made for. The manufacturer is exempted from any liability, contractual and extracontractual, for injury/damage caused to persons/animals and objects, due to installation, adjustment and maintenance errors and improper use.

## INSTALLATION

Installation of the generator and auxiliary equipment in relation to the heating system must comply with all current Standards and Regulations and to those envisioned by the law. Installation must be carried out by authorised staff, who must provide the buyer with a declaration of conformity for the system and will assume full responsibility for final installation and as a consequence the correct functioning of the installed product.

It is necessary to bear in mind all laws and national, regional, provincial and town council Standards present in the country the appliance has been installed.

The Manufacturer cannot be held responsible for the failure to comply with such precautions. It is recommended to wash all the pipes of the system well before installation to remove any residue that could compromise the correct operation of the appliance. During installation, inform the user regarding:

- If water leaks, he must close the water supply and promptly inform the after-sales technical service.
- The system working pressure must be checked periodically. If the generator is not used for a long period of time, it is recommended to contact the after-sales technical service to carry out at least the following operations:
  - Set the master switch to position 0.
  - Close the water taps of both the heating system and the domestic hot water system.
  - Empty the heating system and the domestic hot water system if there is risk of freezing.

## COMMISSIONING

After removing the packaging, ensure that the content is intact and complete.

Otherwise, contact the dealer where the appliance was purchased.

When commissioning the product, verify that all safety and control devices the generator consists of work properly. All electrical components that make up the generator must be replaced with original spare parts exclusively by an authorised technical assistance centre, thereby guaranteeing correct operation.

Before leaving the system, the staff in charge of commissioning must monitor the operation of the generator for at least one complete work cycle. The generator must be serviced at least once a year, programming it in advance with the technical assistance centre

## STANDARDS

The boilers have been designed and realised in compliance with the following Directives:

- ♦ UNI EN 303-5 Boilers for central heating. Boilers for solid fuel, with manual and automatic feeding, with a nominal heat output of up to 500 kW

## DIRECTIVES

- ♦ 2006/42/EC: directive MD

- RED (2014/53/EU)
- 2011/65/EU: directive RoHS 2

## FOR SAFETY

- It is forbidden for the generator to be used by children or unassisted disabled persons.
- Do not touch the generator when you are barefoot or when parts of the body are wet or humid.
- The safety and adjustment devices must not be modified without the authorisation or indications of the manufacturer.
- Do not pull, disconnect, twist electric cables leaving the generator, even if disconnected from the electric power supply mains.
- Do not close or reduce the dimensions of the airing vents in the place of installation.
- The airing vents are indispensable for correct combustion.
- Do not leave the packaging elements within reach of children or unassisted disabled persons.
- The hearth door must always be closed during normal functioning of the product.
- Avoid direct contact with parts of the appliance that tend to heat up during functioning.
- Check for the presence of any obstructions before switching the appliance on following a prolonged standstill period.
- The generator has been designed to function in any climatic condition. In particularly adverse conditions (strong wind, freezing) safety systems may intervene to switch the generator off.
  - If this occurs, contact the technical after-sales service and always disable the safety system.
  - If the flue should catch fire, be equipped with suitable systems for suffocating the flames or request help from the fire service.
  - If the generator should block, indicated by a signal on the display and that is not relative to lack of routine maintenance, contact the technical after-sales centre.



**THESE BOILERS MUST BE USED TO HEAT WATER TO A TEMPERATURE THAT DOES NOT EXCEED BOILING POINT IN THE CONDITIONS OF INSTALLATION.**

*We thank you for having chosen our company; our product is a great heating solution developed from the most advanced technology with top quality machining and modern design, aimed at making you enjoy the fantastic sensation that the heat of a flame gives, in complete safety.*

## **WARNINGS**

This instructions manual is an integral part of the product: make sure that it always accompanies the appliance, even if transferred to another owner or user, or if transferred to another place. If it is damaged or lost, request another copy from the area technician. This product is intended for the use for which it has been expressly designed. The manufacturer is exempt from any liability, contractual and extracontractual, for injury/damage caused to persons/animals and objects, due to installation, adjustment and maintenance errors and improper use.

**Installation must be performed by qualified staff, which assumes complete responsibility for the definitive installation and consequent good functioning of the product installed. One must also bear in mind all laws and national, regional, provincial and town council Standards present in the country in which the appliance has been installed, as well as the instructions contained in this manual.**

**The use of the appliance must comply with all local, regional, national and European regulations.**

**The Manufacturer cannot be held responsible for the failure to comply with such precautions.**

**After removing the packaging, ensure that the content is intact and complete. Otherwise, contact the dealer where the appliance was purchased. All electric components that make up the product must be replaced with original spare parts exclusively by an authorised after-sales centre, thus guaranteeing correct functioning.**

## **SAFETY**

- ◆ **THE APPLIANCE MAY BE USED BY CHILDREN 8 YEARS OF AGE OR OLDER AND INDIVIDUALS WITH REDUCED PHYSICAL, SENSORY, OR MENTAL CAPACITIES OR WITHOUT EXPERIENCE OR THE NECESSARY KNOWLEDGE, PROVIDED THAT THEY ARE SUPERVISED OR HAVE**

RECEIVED INSTRUCTIONS ON SAFE USE OF THE APPLIANCE AND THAT THEY UNDERSTAND THE INHERENT DANGERS.

- ◆ THE GENERATOR MUST NOT BE USED BY PERSONS (INCLUDING CHILDREN) WITH REDUCED PHYSICAL, SENSORY AND MENTAL CAPACITIES OR WHO ARE UNSKILLED PERSONS, UNLESS THEY ARE SUPERVISED AND TRAINED REGARDING USE OF THE APPLIANCE BY A PERSON RESPONSIBLE FOR THEIR SAFETY.
- ◆ THE CLEANING AND MAINTENANCE REQUIRED BY THE USER MUST NOT BE PERFORMED BY CHILDREN WITHOUT SUPERVISION.
- ◆ CHILDREN MUST BE CHECKED TO ENSURE THAT THEY DO NOT PLAY WITH THE APPLIANCE.
- ◆ DO NOT TOUCH THE GENERATOR WHEN YOU ARE BAREFOOT OR WHEN PARTS OF THE BODY ARE WET OR DAMP.
- ◆ IT IS FORBIDDEN TO MODIFY THE APPLIANCE IN ANY WAY.
- ◆ DO NOT PULL, REMOVE, TWIST THE ELECTRICAL CABLES COMING OUT OF THE PRODUCT EVEN IF IT IS DISCONNECTED FROM THE MAINS.
- ◆ IT IS ADVISED TO POSITION THE POWER SUPPLY CABLE SO THAT IT DOES NOT COME INTO CONTACT WITH HOT PARTS OF THE APPLIANCE.
- ◆ THE POWER SUPPLY PLUG MUST BE ACCESSIBLE AFTER INSTALLATION.
- ◆ DO NOT CLOSE OR REDUCE THE DIMENSIONS OF THE AIRING VENTS IN THE PLACE OF INSTALLATION. THE AIRING VENTS ARE ESSENTIAL FOR CORRECT COMBUSTION.
- ◆ DO NOT LEAVE THE PACKAGING ELEMENTS WITHIN REACH OF CHILDREN OR UNASSISTED DISABLED PERSONS.
- ◆ THE HEARTH DOOR MUST ALWAYS BE CLOSED DURING NORMAL FUNCTIONING OF THE PRODUCT.
- ◆ WHEN THE APPLIANCE IS FUNCTIONING AND HOT TO THE TOUCH, ESPECIALLY ALL EXTERNAL SURFACES, ATTENTION MUST BE PAID
- ◆ CHECK FOR THE PRESENCE OF ANY OBSTRUCTIONS BEFORE SWITCHING THE APPLIANCE ON FOLLOWING A PROLONGED PERIOD OF INACTIVITY.
- ◆ THE GENERATOR HAS BEEN DESIGNED TO ADJUST ITSELF AUTOMATICALLY IN PARTICULAR OPERATING CONDITIONS
- ◆ THE GENERATOR HAS BEEN DESIGNED TO FUNCTION IN ANY CLIMATIC CONDITION. IN PARTICULARLY ADVERSE CONDITIONS

(STRONG WIND, FREEZING) SAFETY SYSTEMS MAY INTERVENE THAT SWITCH THE GENERATOR OFF. IF THIS OCCURS, CONTACT THE TECHNICAL AFTER-SALES SERVICE AND ALWAYS DISABLE THE SAFETY SYSTEMS.

- ◆ IN THE EVENT THE FLUE CATCHES FIRE, USE SUITABLE SYSTEMS FOR SUFFOCATING THE FLAMES OR REQUEST HELP FROM THE FIRE BRIGADE.
- ◆ THIS APPLIANCE MUST NOT BE USED TO BURN WASTE
- ◆ DO NOT USE ANY FLAMMABLE LIQUIDS FOR IGNITION
- ◆ DURING THE FILLING PHASE DO NOT PUT THE BAG OF PELLETS INTO CONTACT WITH THE PRODUCT
- ◆ THE MAJOLICAS ARE TOP QUALITY ARTISAN PRODUCTS AND AS SUCH CAN HAVE MICRO-DOTS, CRACKLES AND CHROMATIC IMPERFECTIONS. THESE FEATURES HIGHLIGHT THEIR VALUABLE NATURE. DUE TO THEIR DIFFERENT DILATION COEFFICIENT, THEY PRODUCE CRACKLING, WHICH DEMONSTRATE THEIR EFFECTIVE AUTHENTICITY. TO CLEAN THE MAJOLICAS, IT IS RECOMMENDED TO USE A SOFT, DRY CLOTH. IF A DETERGENT OR LIQUID IS USED, THE LATTER COULD PENETRATE INSIDE THE CRACKLES, HIGHLIGHTING THEM.
- ◆ SINCE THE PRODUCT CAN TURN ON AUTOMATICALLY THANKS TO THE TIMER, OR REMOTELY USING THE DEDICATED APPLICATIONS, IT IS STRICTLY FORBIDDEN TO LEAVE ANY COMBUSTIBLE OBJECT WITHIN THE SAFETY DISTANCES INDICATED ON THE TECHNICAL DATA PLATE.
- ◆ INTERNAL COMBUSTION CHAMBER PARTS CAN BE SUBJECT TO EXTERNAL WARN, IT DOESN'T AFFECT THE FUNCTIONALITY

## ROUTINE MAINTENANCE

Based on Decree 22 January 2008 n°37 art.2, routine maintenance means interventions aimed at reducing degradation due to normal use, as well as dealing with accidental events entailing the need of first interventions, which however do not modify the structure of the system upon which one is intervening or its intended use according to the requirements laid down by the technical standards in force and by the manufacturer's use and maintenance manual.

# INSTALLATION

## GENERAL

The flue gas exhaust and hydraulic connections must be carried out by qualified personnel who must issue installation conformity documentation compliant with national standards.

**The installer must provide the owner or person acting for him, according to the legislation in force, with the declaration of conformity, supplied with:**

- 1) the use and maintenance manual of the appliance and of the system components (such as for example, the smoke ducts, chimney, etc.);
- 2) photocopy or photograph of the chimney plaque;
- 3) system booklet (where applicable).

*The installer must ask to be issued with a receipt stating that the documentation has been provided, and must keep it with a copy of the technical documentation relating to the installation.*

For installation in a condominium, prior approval from the condominium's administrator must be requested.

Where required, check the exhaust gas emissions after installation. Should a sampling point be installed, it must be airtight.

## COMPATIBILITY

Do not install in rooms with a fire hazard. It is also forbidden to install it in living areas with the following characteristics:

1. where there are liquid fuel appliances with continuous or discontinuous operation that draw the combustion air into the room in which they are installed.
2. where there are type B gas appliances intended for heating, with or without domestic hot water production and in adjacent and communicating rooms.
3. where the depression measured in situ between the external and internal environment is greater than 4 Pa.

N.B.: Watertight appliances can also be installed in the cases indicated in points 1, 2 and 3 of this paragraph.

## INSTALLATIONS IN BATHROOMS, BEDROOMS AND STUDIO FLATS


Installation in bathrooms, bedrooms and studio flats is only allowed for sealed or closed hearth appliances with ducted combustion air taken from the outside.

## POSITIONING AND SAFETY DISTANCES

The support surfaces and/or points must have a suitable capacity to bear the overall weight of the appliance, accessories and coverings. If the floor is made of a combustible material, we recommend using a non-combustible material to protect the front part from any burnt material which might fall during routine cleaning operations. The generator must be level to function properly. The side walls, the rear walls and the floor support surface should be made of non-combustible material.

## MINIMUM DISTANCES (PELLET STOVES)

Installation next to flammable or heat-sensitive materials is permitted **only if the special safety distances specified on the label at the beginning of the manual (pag.2) are observed**. If the materials are not flammable, you must keep a side and rear distance of at least 100 mm (without the inserts). For products equipped with rear spacers, wall-mounting installation is permitted exclusively for the rear side.



One must also bear in mind all laws and national, regional, provincial and town council regulations in force in the country in which the appliance has been installed, as well as the instructions contained in this manual.

## PREPARATIONS FOR MAINTENANCE

To carry out extraordinary maintenance operations on the product, it may be necessary to move it away from the adjacent walls. This must be done by a technician authorised to disconnect the combustion product evacuation ducts and then reconnect them. For heaters connected to the hydraulic system, the connection between the system itself and the product must be made in such a way that, when an authorised technician is about to carry out extraordinary maintenance operations, it is possible to move the heater at least 1 metre away from the adjacent walls.

## INSTALLING INSERTS

When installing inserts, access must be prevented to the internal parts of the appliance and it must not be possible to access live parts during extraction operations.

Any wiring, for example the power cable or room probe, must be positioned so as not to be damaged during movement of the insert and must not come into contact with hot parts. If a cavity made of combustible material is installed, we recommend taking all the safety precautions indicated by the installation standards.

## VENTILATION AND AERATION OF INSTALLATION ROOMS

In case of non-airtight heater and/or installation, the ventilation must respect the minimum area indicated below (considering the highest value among those provided):

Appliance categories	Reference standard	Percentage of the net opening section with respect to the appliance fumes outlet section	Minimum net opening value of the ventilation duct
Pellet stoves	UNI EN 14785	-	80 cm <sup>2</sup>
Boilers	UNI EN 303-5	50%	100 cm <sup>2</sup>

Under any condition, including in the presence of extractor hoods and/or of controlled forced ventilation systems, the pressure difference between the generator installation rooms and the outside must always be equal to or less than 4 Pa.

In the presence of type B gas appliances with intermittent operation not intended for heating, they must have their own aeration and/or ventilation opening.

The air inlets must meet the following requirements:

- they must be protected with grids, metal mesh, etc., but without reducing the net useful section;
- they must be made so as to make the maintenance operations possible;
- positioned so that they cannot be obstructed;

The clean and non-contaminated air flow can also be obtained from a room adjacent to that of installation (indirect aeration and ventilation), as long as the flow takes place freely through permanent openings communicating with the outside.

The adjacent room cannot be used as a garage, or to store combustible material or for any other activity with a fire hazard, bathroom, bedroom or common room of the building.

### FLUE GAS EXHAUST

The heat generator works in depression and is equipped with an outlet fan for flue gas extraction. There must be a single exhaust system for the generator. Using a flue that is shared with other devices is not allowed.

The components of the flue gas exhaust system must be chosen in relation to the type of appliance to be installed in compliance with:

- UNI/TS 11278 in the event of metal chimneys, with particular attention to that stated in the specification;
- UNI EN 13063-1 and UNI EN 13063-2, UNI EN 1457, UNI EN 1806 in the event of non-metallic chimneys.
- The length of the horizontal section must be minimal and, in any case, no longer than 3 metres, with a minimum upward slope of 3%;
- There must not be more than 4 direction changes including the one due to the use of the "T" element.
- A "T" fitting with a condensation collection cap must be provided at the base of the vertical section.
- If the exhaust is not inserted in an existing flue, a vertical section with a windproof end piece is required (UNI 10683).
- The vertical duct can be inside or outside the building. If the smoke duct is inserted in an existing flue, it must be certified for solid fuel.
- If the smoke duct is outside the building, it must always be insulated.
- The smoke ducts must have at least one airtight inlet for flue gas sampling.
- All the sections of the flue gas duct must be accessible to inspection.
- Inspection openings must be provided for cleaning.
- If the generator has a fume temperature lower than 160°C+ ambient temperature caused by the high yield (contact technicians) it MUST be resistant to humidity.
- A flue system that does not respect the previous points or, in general, that does not comply with the regulations, may cause condensation phenomena inside it.

### CHIMNEY CAP

The chimney caps must meet the following requirements:

- they must have a useful outlet section no less than double that of the chimney/ducted system on which it is installed;
- they must be adapted in order to prevent the penetration of rain and snow in the chimney/ducted system;
- they must be built so that, in the event of winds coming from all directions and from any angle, the expulsion of combustion products is in any case ensured;


### FOR GERMANY ONLY

**The product can be connected to a shared flue** (multi-connection) provided that the requirements of the regional and national regulations, amongst which DIN EN 13384-2, DIN V 18160-1, DIN 18896 and of the MFeuV-2007 (Muster-Feuerungsverordnung) are strictly complied with, and that the local chimney sweep has checked and approved the installation conditions.

Please also remember the following indications, which the end user must comply with:

- The device can be operated only with the doors closed.
- The doors and all setting devices must remain closed when the device is not on (except for cleaning and maintenance operations).

### EXAMPLES OF CORRECT CONNECTION TO THE CHIMNEY



### CONNECTION TO THE MAINS ELECTRIC SUPPLY

The generator is supplied with an electric power cable to be plugged into a 230V 50 Hz socket, possibly with a circuit breaker switch. The socket must be easily accessible.

The electrical system must be compliant with standards. The efficiency of the earthing circuit must be checked. Unsuitable earthing of the system can cause malfunctioning for which the manufacturer will not be held liable.

Power supply variations beyond 10% can cause faulty operation of the product.

## HYDRAULIC SYSTEM

Certain concepts referring to the Italian UNI 10412-2 Standard are described in this chapter.

As previously described, when installing, all national, regional, provincial and town council Standards in force provided by the country in which the appliance has been installed must be complied with.

When installing the generator, it is MANDATORY to adjust the system with a pressure gauge to display the water pressure.

TABLE OF SAFETY DEVICES FOR CLOSED VESSEL SYSTEM AND NOT PRESENT IN THE PRODUCT	
Safety valve	✓
Pump control thermostat (it is managed by the water probe and the board program)	✓
Water temperature indicator (display)	✓
Pressure transducer with display	X
Automatic circuit breaker adjustment switch (managed by board program)	✓
Manometer	✓
Water overheating automatic circuit breaker switch (block thermostat)	✓
Circulation system (pump)	✓
Expansion system	✓
DSA thermal discharge coil	X
DSA valve (Automatic Safety Device)	X

**Pay attention to the correct sizing of the system:**

- Generator power compared to the thermal requirement
- Possible need for a buffer tank

## INSTALLATION AND SAFETY DEVICES

The installation, relative system connections, commissioning and inspection of correct functioning must be carried out perfectly, in full compliance with Standards in force, national, regional and municipal, as well as these instructions. For Italy, installation must be carried out by professionally qualified staff (Ministerial Decree dated 22.01.08 n°37).

**Extraflame S.p.A. declines all responsibility for damage to objects and/or persons caused by the system.**

### TYPE OF SYSTEM

- There are 2 different types of system:
- Open vessel system and closed vessel system.
- The product has been designed and built to work with closed vessel systems.



**CHECK THAT THE PRELOAD OF THE EXPANSION VESSEL IS SET TO 1.5 BAR.**

## SAFETY DEVICES FOR CLOSED VESSEL SYSTEM

According to the UNI 10412-2 Standard in force in Italy, closed systems must feature the following: safety valve, pump control thermostat, temperature indicator, pressure indicator, automatic temperature regulation device, automatic thermal cut-off switch (safety thermostat), pump system, expansion system.

## DISTANCES OF SAFETY DEVICES ACCORDING TO THE LEGISLATION

The temperature safety sensors must be on the machine at a distance no greater than 30 cm from the flow connection. Whenever the generators lack a device, those missing can be installed on the generator flow pipe, within a distance no greater than 1m from the machine.

## CHECKS WHEN STARTING FOR THE FIRST TIME

Before connecting the boiler:

- a) Discharge the air from the system using the air vent in the boiler and activating the air discharge cycle from the display
- b) wash all system piping thoroughly in order to remove any residues which might compromise the correct operation of certain system components (pumps, valves, etc.).
- c) The company recommends installing a **magnetic filter** in the generator return, to increase the operational life of the boiler, make it easier to remove impurities and increase the overall efficiency of the system.

It is also advisable to perform an inspection using appropriate instruments, to check for any stray currents that may cause corrosion.

- d) Check that the flue has adequate draft, is not narrowed and that other appliances do not discharge into the flue. This is to prevent unexpected power increases. Only after this check can the flue fitting be mounted between the boiler and the flue. It is advisable to check the fittings with pre-existing flues.

## ANTI-CONDENSATION DEVICE (MANDATORY)

It is mandatory to create a suitable anti-condensation circuit, which guarantees a return temperature of the unit of at least 55°C. The anti-condensation valve, for example, is used in solid fuel boilers as it prevents the return of cold water in the exchanger. A high return temperature improves efficiency, reduces the formation of condensation from the fumes and extends the service life of the generator. The manufacturer recommends using the 55°C model with 1" hydraulic connections.



For products with PWM\* pump control, installation is considered equivalent to the creation of a suitable anti-condensation circuit in cases where:

- the heat generator pump is the only one in the system, or
- between the heat generator and the system there is a plate heat exchanger, or
- between the heat generator and the system there is a hydraulic compensator or an inertial storage device (buffer)

\*Check the technical data sheet on the website.


Valve sold as an accessory (optional)

## IDENTIFICATION OF PR COMPONENTS













<b>A</b>	Display	<b>K</b>	Bulb thermostat reactivation
<b>B</b>	Pellet hopper lid	<b>L</b>	Serial input
<b>C</b>	Door	<b>M</b>	TA inlet
<b>D</b>	Combustion fumes exhaust pipe Ø100 (PR20)	<b>T1</b>	3 bar safety drain
<b>E</b>	Combustion fumes exhaust pipe Ø120 (PR30)	<b>T2</b>	Boiler flow/output
<b>F</b>	Ash extractor	<b>T3</b>	Boiler return/input
<b>G</b>	Air intake hose for combustion	<b>T5</b>	Manometer
<b>H</b>	Power outlet for electrical cable	<b>T6</b>	Air vent
<b>I</b>	Fuse		
<b>J</b>	ON/OFF		

## IDENTIFICATION OF PK COMPONENTS



<b>A</b>	Display	<b>J</b>	Bulb thermostat reactivation
<b>B</b>	Pellet hopper lid	<b>K</b>	Serial input
<b>C</b>	Door	<b>L</b>	TA inlet
<b>D</b>	Combustion fumes exhaust pipe Ø100 (PK15-20)	<b>T1</b>	3 bar safety drain
<b>E</b>	Combustion fumes exhaust pipe Ø120 (PK30)	<b>T2</b>	Boiler flow/output
<b>F</b>	Air intake hose for combustion	<b>T3</b>	Boiler return/input
<b>G</b>	Power outlet for electrical cable	<b>T5</b>	Manometer
<b>H</b>	Fuse	<b>T6</b>	Air vent
<b>I</b>	ON/OFF		

**SIDE SMOKE OUTLET PR-PK 15-20****1****2****3****4****5****6***\* NOT SUPPLIED*


**SIDE SMOKE OUTLET PR-PK 30****1****2****3****4****5***\* NOT SUPPLIED*

## BULB THERMOSTAT REACTIVATION

The figure below shows the reactivation position (A). It is recommended to contact the qualified technician if one of the rearms should be triggered, so as to verify the cause.

## FUSE

If the stove is not powered, have the condition of the fuse (B) checked by a qualified technician.



## FEATURES

	PK 15	PK20	PK 30
	PR20	PR30	
Water content of the thermo-product heat exchanger (l)	46	46	63
Volume of expansion vessel integrated into thermo-product (l)	8	8	8
3 bar safety valve integrated into the thermo-product	✓	✓	✓
Pump integrated into the thermo-product	✓	✓	✓
Pump max. head (m)	6	6	6

\* ENVISION ANY INTEGRATIVE EXPANSION VESSEL ON THE BASIS OF THE SYSTEM WATER CONTENT.



CONSULT THE HYDRAULIC DIAGRAMS MANUAL FOR THE DETAILS OF THE CIRCULATOR INSTALLED.



FOR CORRECT GENERATOR OPERATION, THE HYDRAULIC SYSTEM PRESSURE MUST BE BETWEEN 0.6 AND 3 BAR.


## TOUCH SCREEN DISPLAY

The stove is equipped with a modern touch screen display with Wi-Fi technology that allows for the individual functions of the unit to be adjusted by the user in an easy and intuitive manner.

Touch the buttons (icons) on the display to activate the actions. The touch screen display reacts with the touch of your fingers.


### CAUTION!

- Do not use screen protectors: the display might not work properly
- Do not place the touch screen display in direct or indirect contact with water. The touch screen display may not work properly in the presence of humidity or if it is exposed to water.
- To avoid damaging the touch screen display, do not touch it with sharp objects and do not press it too hard with your fingers.
- During opening and closure, press only on the outer frame of the Display.



FREQUENCY BANDS	MAXIMUM POWER TRANSMITTED
Wi-Fi	20.0 DBM
BLUETOOTH	Class-3

## CONTROL BOARD



**1** On/off stove.

**2** Increase operating power / scroll through the menus.

**3** Decrease operating power / scroll through the menus.


**4** Increase operating set thermostat / scroll through the menus.

**5** Decrease operating set thermostat / scroll through the menus.

**6** To access the menu / confirm key.

ICON KEY			
	Indicates the presence of an alarm. Off: indicates there are no alarms On: indicates the presence of an alarm		Delayed switch-off icon. Off: deactivated. On: activated.
	Indicates the reception of the IR signal On = IR command received Off = IR communication absent		Indicates the weekly programming status Off: deactivated. On: activated. The number indicates the current reference time frame.
	Indicates contact of the external additional thermostat Closed contact: the contact of the external additional thermostat is closed. Open contact: the contact of the external additional thermostat is open.	WI-FI	Wi-Fi icon Off: deactivated. On: activated and connected to the home network. Flashing: activated but not connected to the home network.
	Indicates the stove power. Flame on: stable power. Flame flashing: the power is changing. The dashes indicate the actual power of the machine.	STBY	STAND-BY function icon Off: deactivated. On: activated.
	It indicates the operation of the tangential fan. Off = ventilation not active. On = ventilation active. Flashing: ventilation at reduced speed for compensation.		It indicates the operation of the pump. Off = pump stopped. On = pump active. Flashing = electronic anti-condensation function active.
		Not in use	

## GENERAL MENU



\*TECHNICIANS ONLY

## GENERAL WARNINGS

### Advice to follow for the first start-ups of the product:

During the first hours of operation, there may be some smoke or odours, but they are due to the normal "thermal break-in" process. During this process, the duration of which changes depending on the product, it is recommended to:


- Ventilate the room well
- If present, remove any majolica parts from the top of the product
- Activate the product at the maximum power and temperature
- Avoid remaining in the room for a long time
- Do not touch the surfaces of the product

### Notes:


The process is completed after a few heating/cooling cycles. Do not use for the combustion of elements or substances other than those indicated in the manual.

### Before turning on the product, it is necessary to perform the following checks:

- If it is intended to be connected to a hydraulic system, it must be complete and fully functional and in compliance with the instructions given in the product manual and with the relevant regulations in force.
- The pellet hopper must be completely loaded
- The combustion chamber and the burn pot must be clean
- Make sure that the fire holder, the ash pan and the pellet hopper close hermetically (if present in the hermetic version); they must be closed and there must be no foreign bodies in the sealing elements and gaskets.
- Check that the power cord is properly connected
- The switch (if present) must be set to position "1".



**MAKE SURE THAT THE BOTTOM OF THE BURN POT IS FREE FROM RESIDUE AND DEPOSITS. THE HOLES AT THE BOTTOM MUST BE COMPLETELY FREE TO GUARANTEE PROPER COMBUSTION.**



## FIRST IGNITION SETTINGS

Once the power cord at the back of the stove has been connected, move the switch, also located on the back, to (I). The switch at the back of the stove powers the stove board.

### DATE-TIME

This menu allows the date and time to be set.

#### CONTROLS PROCEDURE

- ◆ Press key 6.
- ◆ Press key 3 until **SETTINGS** appears and confirm by pressing key 6.
- ◆ Confirm **DATE-TIME** by pressing key 6 and using keys 4 and 5 to set the day.
- ◆ Continue by pressing key 6.
- ◆ Use the same procedure with 4 or 5 to choose the setting and 6 to move continue, to set the hour, minutes, date, month and year.
- ◆ Press key 6 to confirm and key 1 to scroll back through the menus until the initial page.

### LANGUAGE

This menu allows the preferred language to be selected.

The available languages are: Italian - English - German - French - Spanish - Portuguese - Danish - Estonian - Croatian - Slovenian - Dutch - Polish - Czech.

#### CONTROLS PROCEDURE

- ◆ Press key 6.
- ◆ Press key 3 until **SETTINGS** appears and confirm by pressing key 6.
- ◆ Press key 3 until **LANGUAGE** appears and confirm by pressing key 6.
- ◆ Select the language using keys 4 or 5.
- ◆ Press key 6 to confirm and key 1 to scroll back through the menus until the initial page.

### DEGREES

This menu allows you to set the unit of measure for the temperature. The value is preset to °C.

#### CONTROLS PROCEDURE

- ◆ Press key 6.
- ◆ Press key 3 until **SETTINGS** appears and confirm by pressing key 6.
- ◆ Press key 3 until **DEGREES** appears and confirm by pressing key 6.
- ◆ Use keys 4-5 to select Celsius or Fahrenheit.
- ◆ Press key 6 to confirm and key 1 to scroll back through the menus until the initial page.



**DO NOT USE ANY FLAMMABLE LIQUIDS FOR IGNITION!**  
**DO NOT ALLOW THE BAG OF PELLETS TO COME INTO CONTACT WITH THE BOILING HOT STOVE DURING THE FILLING PHASE!**  
**IN THE EVENT OF CONTINUED FAILURE TO LIGHT, CONTACT AN AUTHORISED TECHNICIAN.**



#### NO IGNITION

**THE APPLIANCE MAY FAIL TO LIGHT BECAUSE THE AUGER IS EMPTY AND NOT ALWAYS ABLE TO LOAD THE BURN POT FAST ENOUGH WITH THE PELLETS NEEDED FOR NORMAL IGNITION. IF THE PROBLEM OCCURS AFTER ONLY A FEW MONTHS OF OPERATION, CHECK THAT THE ROUTINE CLEANING DESCRIBED IN THE STOVE HANDBOOK HAS BEEN CARRIED OUT CORRECTLY**

## OPERATION AND LOGIC

### IGNITION

Once the points listed previously have been checked, press key 1 for three seconds to ignite the stove. 15 minutes are available for the ignition phase. After ignition and having reached the control temperature, the stove interrupts the ignition phase and passes to STARTING.

### PREPARATION

During the start-up phase, the stove stabilises combustion, increasing it progressively, to then start ventilation and pass on to WORK.

### WORK

During the work phase, the stove reaches the set power set; see following item.

### SET POWER

Set the operating power from 1 to 5 (using keys 2 and 3).

Power 1 = minimum level - Power 5 = maximum level.

### SET H2O

Set the boiler temperature from 65 to 80°C (using keys 4 and 5).

### PUMP OPERATION

The pump is activated when the internal water temperature reaches 60°C. Since the pump is always in operation above 60°C, it is advisable to keep a heating area always open so that the product operates in a more homogeneous manner and in order to prevent stoppages due to overtemperature. This area is usually called "safety area".

### BURN POT CLEANING

At preset intervals, the generator cleans the burn pot, turning the machine off.

When the cleaning phase is finished, the generator will re-start automatically and continue the working phase, returning to the selected power level.

### BLOW

During the working phase, the stove has an internal timer, which after a pre-set period of time cleans the burn pot.

This phase is shown on the display, it lowers the stove power level and increases the flue gas exhaust motor for a programmed period of time.

When the cleaning phase is finished, the stove will re-start automatically and continue the working phase, returning to the selected power level.

### MODULATION and H-OFF

As the water temperature approaches the set point, the boiler starts to modulate automatically bringing itself to the minimum power. If the temperature increases beyond the set point, it will automatically switch off indicating H-OFF, and will automatically go back on when the temperature drops below the set point.

### SWITCH-OFF

Press key 1 for three seconds.

Once this operation has been performed, the appliance automatically enters the switch-off phase, blocking the supply of pellets.


**The flue gas exhaust motor and the hot air flow motor will remain on until the stove temperature has dropped below the default parameters.**

### REIGNITION

The stove can only be re-ignited automatically or manually when the cooling cycle conditions and the preset timer have been satisfied.



**IT IS PROHIBITED TO USE THE APPLIANCE WITHOUT THE PARTITION AND OR FLAME GUARD (SEE FIGURE ON SIDE). REMOVAL WILL COMPROMISE THE SAFETY OF THE PRODUCT AND RESULT IN THE IMMEDIATE NULLIFICATION OF THE WARRANTY PERIOD. IN THE CASE OF WEAR OR DETERIORATION, REQUEST AFTER-SALES ASSISTANCE TO REPLACE THE PART (REPLACEMENT IS NOT COVERED BY THE WARRANTY AS THE COMPONENT IS SUBJECT TO WEAR).**



## STAND-BY - ADDITIONAL THERMOSTAT

### **N.B. : INSTALLATION MUST BE PERFORMED BY AN AUTHORISED TECHNICIAN**

It is possible to control the temperature of a room adjacent to the room where the stove is positioned; simply connect a thermostat following the procedure described in the following section (it is advisable to place the optional mechanical thermostat at a height off the ground equal to 1.50 m). Stove operation with the external thermostat connected in the clamp TA can be different depending on the activation or deactivation of the STAND-BY function.

**By factory default, the clamp TA is jumpered, therefore it always has closed contact (on request).**

### **ADDITIONAL THERMOSTAT FUNCTIONING WITH STAND-BY ACTIVE**

When the STAND-BY function is active, the S<sub>T</sub>BY icon will be on. When the contact or external thermostat is not satisfied (open contact / temperature reached), the stove will switch off. As soon as the contact or external thermostat switches to the "not satisfied" status (closed contact / temperature to be reached) it will re-ignite.

**NB: stove operation depends on the temperature of the water inside the stove and relative factory setting restrictions. If the stove is in H-OFF (water temperature reached), any additional contact or thermostat request will be ignored.**

### **ADDITIONAL THERMOSTAT OPERATION WITH STAND-BY DEACTIVATED**

When the STAND-BY function is not active, the S<sub>T</sub>BY icon will be off.

When the contact or external thermostat is satisfied (open contact / temperature reached), the stove will go to minimum. As soon as the contact or external thermostat switches to the "not satisfied" status (closed contact / temperature to be reached) the stove will start to work again at the pre-set power.


**NB: stove operation depends on the temperature of the water inside the stove and relative factory setting restrictions. If the stove is in H-OFF (water temperature reached), any additional contact or thermostat request will be ignored.**

### **ADDITIONAL THERMOSTAT INSTALLATION**


- ◆ A mechanical or digital thermostat with a "normally open" input is required.
- ◆ Remove the plug from the socket.
- ◆ Using the figure as a reference, connect the two thermostat cables (clean contact - no 230 V!).
- ◆ Connect the power to the stove again.



**TO ACTIVATE STAND-BY, REFER TO THE "SETTINGS" CHAPTER**



## CHRONO



This function allows stove ignition and switch-off to be automatically programmed.

The factory setting for CHRONO is off.

The chrono allows the programming of 4 time slots per day, which can be used every day of the week.

**For each time slot, it is possible to set ignition and switch-off times, specific days of application, desired temperature and set power. Current day and time settings are essential for the correct operation of the Chrono.**

### Recommendations

Before using the chrono function, you must set the current day and time, so check that you have followed the points listed in the sub-chapter "DATE-TIME". To use the chrono function correctly, it must not only be programmed, but also enabled. The 4 time slots can be overlapped using the ignition and switch-off time settings. In this way, it is possible to create a combination of time slots with different temperatures and power levels, without changing the status of the stove.

N.B.: in the case of overlapping time slots, the stove will remain on until the last switch-off time.

### ENABLING/DISABLING THE CHRONO

#### CONTROLS PROCEDURE




- ◆ Press key 6.
- ◆ Press 3 until **CHRONO** appears and confirm by pressing key 6.
- ◆ Confirm **ENABLING** by pressing 6.
- ◆ Use keys 4 -5 to enable (ON) or disable (OFF)
- ◆ Press key 6 to confirm and key 1 to scroll back through the menus until the initial page.

<b>CHRONO</b>	>	<b>ENABLING</b>	>	<b>PRG1</b>	<i>On/off</i>	<i>Enable/disable PRG 1</i>
	v			<b>PRG2</b>	<i>On/off</i>	<i>Enable/disable PRG 2</i>
	v			<b>PRG3</b>	<i>On/off</i>	<i>Enable/disable PRG 3</i>
	v			<b>PRG4</b>	<i>On/off</i>	<i>Enable/disable PRG 4</i>
		<b>PRG1</b>	>	<b>START PRG1</b>	<i>OFF-00:00</i>	<i>PRG1 ignition time</i>
	v			<b>STOP PRG1</b>	<i>OFF-00:00</i>	<i>PRG1 switch-off time</i>
	v			<b>MONDAY...SUNDAY</b>	<i>On/off</i>	<i>Enable/disable days PRG1</i>
	v			<b>SET PRG1</b>	<i>65°C - 80°C (149°F - 176°F)</i>	<i>SET H2O PRG1</i>
	v			<b>POWER PRG1</b>	<i>1-5</i>	<i>Set power PRG1</i>
		<b>PRG2</b>	>	<b>START PRG2</b>	<i>OFF-00:00</i>	<i>Ignition time PRG2</i>
	v			<b>STOP PRG2</b>	<i>OFF-00:00</i>	<i>Switch-off time PRG2</i>
	v			<b>MONDAY...SUNDAY</b>	<i>On/off</i>	<i>Enable/disable days PRG2</i>
	v			<b>SET PRG2</b>	<i>65°C - 80°C (149°F - 176°F)</i>	<i>SET H2O PRG2</i>
	v			<b>POWER PRG2</b>	<i>1-5</i>	<i>Set power PRG2</i>
		<b>PRG3</b>	>	<b>START PRG3</b>	<i>OFF-00:00</i>	<i>Ignition time PRG3</i>
	v			<b>STOP PRG3</b>	<i>OFF-00:00</i>	<i>Switch-off time PRG3</i>
	v			<b>MONDAY...SUNDAY</b>	<i>On/off</i>	<i>Enable/disable days PRG3</i>
	v			<b>SET PRG3</b>	<i>65°C - 80°C (149°F - 176°F)</i>	<i>SET H2O PRG3</i>
	v			<b>POWER PRG3</b>	<i>1-5</i>	<i>Set power PRG3</i>
		<b>PRG4</b>	>	<b>START PRG4</b>	<i>OFF-00:00</i>	<i>Ignition time PRG4</i>
				<b>STOP PRG4</b>	<i>OFF-00:00</i>	<i>Switch-off time PRG4</i>
				<b>MONDAY...SUNDAY</b>	<i>On/off</i>	<i>Enable/disable days PRG4</i>
				<b>SET PRG4</b>	<i>65°C - 80°C (149°F - 176°F)</i>	<i>SET H2O PRG4</i>
				<b>POWER PRG4</b>	<i>1-5</i>	<i>Set power PRG4</i>



IF WEEKLY PROGRAMMER IS ACTIVE ON THE COMMAND PANEL, A SMALL ICON IS DISPLAYED



**EXAMPLE OF CHRONO OVERLAPPING TIMES/SLOTS**
**TIME SLOT**

**SET POWER**

**SET H<sub>2</sub>O**


	Time slot 1	start 02:00 stop 23:00	power 3 - SET H <sub>2</sub> O 72°C
	Time slot 2	start 08:00 stop 16:30	power 1 - SET H <sub>2</sub> O 68°C
	stove operation		

## SETTINGS

- **DATE-TIME**
- **LANGUAGE**
- **SET DEGREES**

*SEE CHAPTER: FIRST IGNITION SETTINGS*

### DISPLAY

This menu allows you to adjust the brightness of the display. The values range from OFF, 1 to 20. If set to OFF, the display backlighting is set to maximum brightness and turns off after a 60 second delay.

The backlighting can be turned on again by pressing any key or if the stove is in alarm status.

#### CONTROLS PROCEDURE

- ◆ Press key 6.
- ◆ Press key 3 until **SETTINGS** appears and confirm by pressing key 6.
- ◆ Keep pressing key 3 until **DISPLAY** appears and confirm by pressing key 6.
- ◆ Use keys 4-5 to set the desired intensity (**SET**)
- ◆ Press key 6 to confirm and key 1 to scroll back through the menus until the initial page.

### STAND - BY

The **STAND-BY** function, if enabled, is used when stove switch-off is to be controlled by means of an additional thermostat

#### CONTROLS PROCEDURE

- ◆ Press key 6.
- ◆ Press key 3 until **SETTINGS** appears and confirm by pressing key 6.
- ◆ Keep pressing key 3 until **STAND-BY** appears and confirm by pressing key 6.
- ◆ Use keys 4-5 to enable (**ON**) / disable (**OFF**).
- ◆ Press 1 several times to confirm and exit the menu

### FIRST LOAD

This function allows the auger to be filled, thus facilitating first stove ignition phases, or in the event the pellet hopper is empty.

With the stove cold and "OFF", make sure the pellets have been introduced inside the hopper and activate the **FIRST LOAD** function, confirming by pressing **OK**.

To interrupt continuous loading, simply press key 1 for 3 seconds.

#### CONTROLS PROCEDURE

- ◆ Press key 6.
- ◆ Press key 3 until **SETTINGS** appears and confirm by pressing key 6.
- ◆ Keep pressing key 3 until **FIRST LOAD** appears and confirm by pressing key 6.
- ◆ Press key 1 several times to confirm and exit the menu.

### OUTLET AIR

This function allows any air in the stove to be discharged. By activating the pump function, it will be powered alternatively with 30 second work phases and 30" stop for 15 minutes. With the stove cold and in "OFF", activate the **OUTLET AIR** function, pressing key 6 to confirm. To interrupt, press and hold key 1 for 3 seconds.

Attention: before activating the "**OUTLET AIR**" function, make sure you have opened the vent screw of the manual vent valve.

#### CONTROLS PROCEDURE

- ◆ Press key 6.
- ◆ Press key 3 until **SETTINGS** appears and confirm by pressing key 6.
- ◆ Keep pressing 3 until **OUTLET AIR** appears and confirm by pressing 6.
- ◆ Press key 1 several times to confirm and exit the menu.

## ROUTINE CLEANING

This function allows to open the burn pot base, facilitating the combustion chamber cleaning operations.

With the stove cold and switched "OFF", activate the **CLEANING** function.

Once the burn pot bottom has been opened completely, scrape the walls of the combustion chamber using the special tool supplied and let the residual ash drop into the ash drawer.

### CONTROLS PROCEDURE:

- ◆ Press key 6
- ◆ Press 3 until **SETTINGS** appears and confirm by pressing 6
- ◆ Keep pressing 3 until **ROUTINE CLEANING** appears and confirm by pressing 6
- ◆ Scrape the walls of the combustion chamber using the special tool supplied and let the residual ash drop into the ash drawer.
- ◆ Press key 1 to end and wait for the main screen to reappear.

**OPEN THE DOOR ONLY WHEN THE OPERATION IS COMPLETE! THE DISPLAY WILL INDICATE THAT THE DOOR HAS BEEN OPENED!**

## Wi-Fi

The display allows internet connection using Wi-Fi technology.

This allows remote management and control of the stove using the dedicated APP for Smartphones, "TotalControl 2.0" (Apple Store / Play Store).

### WI-FI ENABLING CONTROLS PROCEDURE

- ◆ Press key 6.
- ◆ Press key 3 until **SETTINGS** appears and confirm by pressing key 6.
- ◆ Keep pressing key 3 until **Wi-Fi** appears and confirm by pressing key 6.
- ◆ Press key 6 to access **ENABLING**.
- ◆ Use keys 4-5 to select enabling "ON" / disabling "OFF" and press key 6 to confirm.
- ◆ Press key 1 several times to exit the menu.

### CONTROLS PROCEDURE TO RESET WI-FI CONFIGURATION AND ENABLE ACCESS POINT

- ◆ Press key 6.
- ◆ Press key 3 until **SETTINGS** appears and confirm by pressing key 6.
- ◆ Press key 3 until **Wi-Fi** appears and confirm by pressing key 6.
- ◆ Press key 3 until **RESET** appears and the press key 6.
- ◆ Use keys 4-5 to select start reset "ON" / "OFF" and press key 6 to confirm.
- ◆ Press key 1 several times to exit the menu.

## RESET

Allows the user to reset all editable values to the default values.

### CONTROLS PROCEDURE

- ◆ Press key 6.
- ◆ Press key 3 until **SETTINGS** appears and confirm by pressing key 6.
- ◆ Press key 3 until **RESET** appears and confirm by pressing key 6.
- ◆ Use keys 4-5 for enabling "ON" or disabling "OFF"
- ◆ Press key 1 several times to confirm and exit the menu.

## AUX

If the producer's conveyed wave accessories are used, the connection must be made by the qualified technician directly in the board. Contact the dealer for further details.

## OPTIONAL ADDITIONAL BOARD (STANDARD ON PR20 AND PR30)

The manufacturer has an optional additional board which allows the boiler to have the following additional system management functions. The table below indicates the various possibilities that the optional can offer.

DHW Storage Management	✓
Buffer Tank management	✓
3 heating areas	✓
Instant DHW option	✓
Buffer tank pump or 4th heating area management	✓
Anti-legionella management for DHW storage	✓
DHW storage chrono management	✓
Auxiliary output management and control	✓

TO FIND OUT WHERE YOUR NEAREST SERVICE CENTRE IS, CONTACT YOUR DEALER OR VISIT THE WEBSITE: [WWW.LANORDICA-EXTRAFLAME.COM](http://WWW.LANORDICA-EXTRAFLAME.COM)

## CLEANING AND MAINTENANCE

ALWAYS FOLLOW THE INSTRUCTIONS IN COMPLETE SAFETY!

- ♦ FOR ALL OPERATIONS, EXCEPT FOR ROUTINE CLEANING, MAKE SURE THAT THE POWER CORD PLUG IS DISCONNECTED AS THE GENERATOR MAY HAVE BEEN PROGRAMMED TO TURN ON.
- ♦ THAT THE GENERATOR IS COLD ALL OVER.
- ♦ THAT THE ASHES ARE COMPLETELY COLD.
- ♦ ENSURE EFFICIENT AIR EXCHANGE IN THE ROOM DURING PRODUCT CLEANING OPERATIONS.
- ♦ POOR CLEANING WILL COMPROMISE CORRECT OPERATION AND SAFETY!

## MAINTENANCE

For correct operation, the generator must undergo routine maintenance by a qualified technician, at least once a year. The periodic inspection and maintenance operations must always be performed by specialised, qualified technicians, who operate in accordance with the laws in force and the instructions given in this use and maintenance manual.



**EVERY YEAR, HAVE THE FUME EXTRACTION SYSTEM, FLUE PIPES AND "T" FITTINGS, INCLUDING THE INSPECTION CAPS CLEANED. IF PRESENT, ALSO CLEAN THE ELBOWS AND HORIZONTAL SECTIONS!**  
**THE GENERATOR CLEANING FREQUENCY IS INDICATIVE! IT DEPENDS ON THE QUALITY OF THE PELLETS AND FREQUENCY OF USE.**  
**THESE OPERATIONS MAY SOMETIMES NEED TO BE PERFORMED MORE OFTEN**

## PERIODIC CLEANING UNDER USER'S RESPONSIBILITY

The periodic cleaning operations, as indicated in this use and maintenance manual, must be performed with the utmost care after reading the instructions, procedures and frequency described in this use and maintenance manual.

### CLEANING THE SURFACES AND COVERING

**Never use abrasive or chemically aggressive detergents for cleaning!**

The surfaces must be cleaned when the generator and covering are completely cold. For the maintenance of the surfaces and metal parts, simply use a cloth dampened with water or water and neutral soap.

Failure to comply with these instructions may damage the surfaces of the generator and cause the invalidation of the warranty.

### CLEANING THE CERAMIC GLASS

**Never use abrasive or chemically aggressive detergents for cleaning!**

The ceramic glass must be cleaned when the glass is completely cold.

To clean the ceramic glass, simply use a dry brush and some damp newspaper dipped in ash. If the glass is very dirty, use a specific cleaning agent for ceramic glass. Spray a small amount on a cloth and use it on the ceramic glass. Do not spray the cleaning agent or any other liquid directly on the glass or seals!

Failure to comply with these instructions may damage the surfaces of the ceramic glass and cause the invalidation of the warranty.

### CLEANING THE PELLET HOPPER

When the hopper is completely empty, disconnect the power cord of the generator, remove the residue (dust, chippings, etc.) from the empty hopper and then fill it up.



**THE PELLET HOPPER GASKETS, BURN POT AND FIRE DOOR GUARANTEE CORRECT STOVE OPERATION. THESE NEED TO BE PERIODICALLY CHECKED BY THE USER. IF THEY ARE WORN OR DAMAGED, IMMEDIATELY REPLACE THEM.**  
**THESE OPERATIONS MUST BE CARRIED OUT BY A QUALIFIED TECHNICIAN.**




**IF THE POWER CORD IS DAMAGED, IT MUST BE REPLACED BY THE SERVICE CENTRE OR BY A SIMILARLY QUALIFIED PERSON, SO AS TO AVOID ALL RISKS.**

## BURN POT AND COMBUSTION CHAMBER

By means of a mechanical system, the burn pot is cleaned automatically at preset intervals. **It is however advisable to remove any residues by means of a vacuum cleaner.**


- Remove the assembly made up of the internal cone (A) and the ash conveyor (B).
- Clean the combustion chamber and the bottom of the burn pot completely, using a suitable vacuum cleaner.



## CLEANING THE COMBUSTION CHAMBER TUBE BUNDLE

Clean the 6 tube bundles (B) of the combustion chamber using the brush supplied (A).

It is advisable to use a suitable vacuum cleaner during the operation.





## DETAILS ON BURN POT CLEANING

To clean the burn pot, simply remove the central cone (A), lift the flame guard (B) and rotate it to remove it completely. Perform the same operation in reverse order to re-assemble.

After having re-positioned, always make sure:


- that the cone (A) has been inserted in the correct direction (see figure);
- that the ash conveyor (B) rests on the burn pot correctly, and not on another area of the combustion chamber.






## A CLEAN BURN POT GUARANTEES CORRECT OPERATION!

BY KEEPING THE BURN POT AND ITS HOLES CONSTANTLY CLEAN AND FREE OF COMBUSTION RESIDUE, EXCELLENT COMBUSTION IS GUARANTEED OVER TIME, THUS PREVENTING ANY GENERATOR MALFUNCTIONS THAT MAY REQUIRE TECHNICAL ASSISTANCE.





## ASH DRAWER (PK VERSION)

- Turn off the boiler
- Remove the ash drawer and empty it into a suitable container.



## ASH COMPACTOR (FOR PR VERSION ONLY)

- Turn off the boiler
- Release the compactor from the boiler by means of the two lateral levers (A).
- Close the cap (B) on the auger insertion hole (to prevent ash from falling while it is being moved)
- Release the cap (C) and empty out the ash.
- Close the cap (C).
- Open the hole (B) to insert the auger and insert the compactor.
- Secure the compactor by means of the two lateral levers (A).



## CLEANING AND MAINTENANCE SUMMARY TABLE

USER CLEANING		FREQUENCY - EVERY X *PALLET CONSUMED
BURN POT COMBUSTION CHAMBER	PK15	1
	PK20	1
	PK30	1
	PR20	2
	PR30	2
ASH DRAWER (PK)	PK15	1
	PK20	1
	PK30	1
**CLEANING THE ASH COMPACTOR (PR)	PR20	2
	PR30	2
CLEANING THE COMBUSTION CHAMBER TUBE BUNDLE	PK-PR	3

\*1 Pallet = 1050kg

QUALIFIED TECHNICIAN		FREQUENCY - EVERY XX MONTHS
CLEANING THE EXCHANGER	PK-PR	12
T-SHAPED FITTING/ FLUE PIPE	PK-PR	6
GASKETS	PK-PR	12



\*\*COMPACTOR CLEANING: IN CASE OF PROLONGED BOILER INACTIVITY (MORE THAN 60 DAYS) CHECK THAT THE ASH IN THE COMPACTOR HAS NOT BEEN SOLIDIFIED BY MOISTURE.



THE GENERATOR CLEANING FREQUENCY IS INDICATIVE! IT DEPENDS ON THE QUALITY OF THE PELLETS AND FREQUENCY OF USE.  
THESE OPERATIONS MAY SOMETIMES NEED TO BE PERFORMED MORE OFTEN

## ROUTINE MAINTENANCE PERFORMED BY QUALIFIED TECHNICIANS

### Routine maintenance must be performed at least once a year.

Given the generator uses pellets as solid fuel, it requires annual routine maintenance, which must be performed by a **Qualified technician, using only original spare parts.**

Failure to comply may jeopardise safety of the appliance and invalidate the warranty conditions.

By observing the cleaning schedule reserved to the user described in the use and maintenance manual, the generator will be guaranteed correct combustion over time, thus preventing any faults and/or malfunctions which may require subsequent technical assistance. Requests for routine maintenance are not covered by the warranty.

### DOOR, ASH DRAWER AND BURN POT GASKETS

The gaskets ensure the proper sealing of the stove and therefore its proper operation.

They must be periodically checked and immediately replaced if worn or damaged.

These operations must be carried out by a qualified technician.

### CONNECTION TO THE FLUE

Annually, or in any case each time the flue pipe needs to be vacuumed and cleaned. If there are horizontal sections, the residue must be removed to prevent it from obstructing the flow of fumes.

### SHUT-DOWN (END OF SEASON)


At the end of each season, before turning the stove off, it is advisable to completely empty the pellet hopper, removing any pellet residue and dust with a vacuum cleaner.

**IT IS ADVISABLE NOT TO DISCONNECT THE HEAT GENERATOR FROM THE ELECTRICAL POWER SUPPLY IN ORDER TO ALLOW THE PUMP TO PERFORM THE NORMAL ANTI-BLOCKING CYCLES.**

Routine maintenance must be performed at least once a year.

## ROUTINE MAINTENANCE

THE PICTURES ARE FOR ILLUSTRATIVE PURPOSES ONLY.



<b>A</b>	Fumes motor (disassembly and cleaning and fumes pipe and "T"), new silicone in the provided points
<b>B</b>	Inspections of gaskets, ash drawer and door (replace them and apply silicone where envisioned)
<b>C</b>	Combustion chamber and heat exchanger (full cleaning) including ignition plug pipe
<b>D</b>	Hopper (complete emptying and cleaning).
<b>E</b>	Check air intake pipe and cleaning of the flow sensor
<b>G</b>	Manual purge valve

## DISPLAYS

DISPLAY	REASON
<b>OFF</b>	Generator off
<b>START</b>	The start-up phase is in progress
<b>PELLET LOADING</b>	Continuous pellet loading is in progress during the ignition phase
<b>IGNITION</b>	The ignition phase is in progress
<b>PREPARATION</b>	The preparation phase is in progress.
<b>WORK</b>	The normal work phase is in progress.
<b>MODULATION</b>	The generator is working at minimum.
<b>BLOW</b>	The automatic blow is active.
<b>BURN POT CLEANING</b>	The routine cleaning of the burn pot is in progress.
<b>FINAL CLEANING</b>	The final cleaning is in progress.
<b>STAND-BY</b>	Generator off waiting for re-ignition due to an external thermostat.
<b>COOLING WAITING TIME</b>	The generator is required to turn on during the switch-off phase. If activated, the generator will turn on automatically as soon as the safety conditions allow it.
<b>H-OFF</b>	Generator off due to water temperature over set.
<b>T-OFF</b>	Generator off waiting for re-ignition due to all requests met
<b>WAITING BLACK OUT</b>	The generator is cooling after a power cut. Once cooling is completed, it will re-start automatically
<b>ANTI-FREEZING</b>	The anti-freezing function is in progress as the H2O temperature is below the factory set threshold the pump is active until the water reaches the pre-set factory parameter +2°C
<b>ANTI-BLOCK</b>	The pump anti-block function is in progress (only if the generator has been in an OFF state for at least 96 hours); the pump is activated for the time pre-set by the manufacturer, in order to prevent it from blocking
<b>EXCHANGER BLOCKED</b>	The movement of the exchangers is blocked. Switch off the machine and clean the exchangers. If the problem persists, contact the after-sales centre.
<b>ASH KIT CHECK</b>	The ash extractor is blocked. Switch off the machine and empty out the ash drawer. If the problem persists, contact the after-sales centre.
<b>EMPTY HOPPER</b>	The pellet hopper is empty. Check for the presence of pellets in the hopper.
<b>CLOSE HOPPER-STOVE DOOR</b>	This indication means that you have 60 seconds to close the hatch/door and the pellet lid. After 60 seconds have passed, the stove will enter "DEPR ALARM" during the ignition phase while during normal operation, the stove will enter "COOLING STAND BY" and then, restart automatically when the conditions are right (cold stove, etc.).
<b>DEACT.BULB THERM.</b>	Contact after-sales centre

## ALARMS

DISPLAY	EXPLANATION	SOLUTION
	Indicates the presence of an alarm.	On: indicates the presence of an alarm Flashing: indicates the deactivation of the depression sensor. The alarm can be reset only if the fumes motor has stopped and 15 minutes have passed since the alarm was displayed, by pressing the key 1/  for 3 seconds.
<b>FUMES MOTOR FAULT</b>	Fumes motor fault	Contact after-sales centre

<b>FUMES PROBE</b>	Fumes probe fault.	Contact after-sales centre
<b>HOT FUMES</b>	High fumes temperature	Contact after-sales centre
<b>CHAMBER PROBE</b>	Chamber probe fault.	Contact the after-sales centre.
<b>NO FLAME</b>	The pellet hopper is empty. No pellet feed. The gearmotor does not feed pellets.	Check for the presence of pellets in the hopper. Contact after-sales centre
<b>DEPR ALARM</b>	The door is not closed correctly. The ash drawer is not closed correctly. The combustion chamber/ tube bundle is dirty. The fumes exhaust pipe is blocked/dirty	Check hermetic door closure. Check hermetic closure of the ash drawer. Check cleanliness of the fumes pipe and the combustion chamber/ tube bundle.
<b>NO IGNITION</b>	The pellet hopper is empty. Pellet feed calibration inadequate. Thermostat bulbs tripped.	Check for the presence of pellets in the hopper. Contact after-sales centre. Check the procedures described in the "Ignition" chapter. Check bulb thermostats (see chapter on Resetting)
<b>NO IGNITION BLACK OUT</b>	No current during the ignition phase.	Take the stove to OFF conditions using key 1 and repeat the procedure described in the "Ignition" chapter.
<b>AUGER COMMAND</b>	Abnormal pellet loading.	Contact after-sales centre
<b>AUGER BLOCKED</b>	Abnormal operation of pellet motor	Contact after-sales centre
<b>MAX ELECTRICAL CURRENT</b>	The automatic cleaning of the burn pot is blocked. Burn pot dirty or clogged or door not closed properly	Check that the door is closed properly Check that the burn pot is free and clean If the problem persists, contact the after-sales centre.
<b>H2O PROBE</b>	H2O probe fault	Contact after-sales centre
<b>* DHW PROBE</b>	Fault in <b>DHW probe</b> .	Contact after-sales centre
<b>* BUFFER TANK PROBE</b>	Fault in <b>Buffer tank probe</b> .	Contact after-sales centre
<b>BLOCKED PWM ALARM</b>	The pump has stopped permanently Pump blocked. Electronic module damaged	Contact after-sales centre
<b>HOT PWM ALARM</b>	The pump is operating but not with good performance. Undervoltage 160-194V. Pump in circuit breaker protection mode.	Contact after-sales centre
<b>STOPPED PWM ALARM</b>	The pump has stopped but is still operational. Undervoltage < 160V. Overvoltage. Unexpected external flow.	Contact after-sales centre
<b>STOPPED 2 PWM ALARM</b>	The pump has stopped but is still operational. Problem in a component different to the pump. Debris in installation. Positioning in high temperature.	Contact after-sales centre
<b>FLOW PWM ALARM</b>	Pump blocked. Liquid with high density. Pipe obstructed. Presence of air in the system.	Contact after-sales centre
<b>PWM INTERFACE ALARM</b>	IPWM output interface damaged, in short circuit or not connected	Contact after-sales centre
<b>TRAPDOOR BLOCKED</b>	The automatic cleaning of the burn pot is blocked. Burn pot dirty or clogged The door is not closed properly.	Make sure that the door is closed properly. Make sure that the burn pot is clear and clean. The automatic cleaning of the burn pot is blocked. If the problem persists, contact the service centre
<b>FAULT ALARM DELTA-P</b>	Delta-P Transducer faulty or disconnected.	Contact after-sales centre
<b>EXCESS AIR</b>	Excess combustion air.	Check flue draught. Contact the after-sales centre.

\* if there is an additional system data-sheet.

TO FIND OUT WHERE YOUR NEAREST SERVICE CENTRE IS, CONTACT YOUR DEALER OR GO TO THE WEBSITE [WWW.LANORDICA-EXTRAFIAME.COM](http://WWW.LANORDICA-EXTRAFIAME.COM)

## DISPOSAL

### INFORMATION FOR MANAGEMENT OF ELECTRIC AND ELECTRONIC APPLIANCE WASTE CONTAINING BATTERIES OR ACCUMULATORS



This symbol, which is used on the product, batteries, accumulators or on the packaging or documents, means that at the end of its useful life, this product, the batteries and the accumulators included must not be collected, recycled or disposed of together with domestic waste. Improper management of electric or electronic waste or batteries or accumulators can lead to the leakage of hazardous substances contained in the product. For the purpose of preventing damage to health or the environment, users are kindly asked to separate this equipment and/or batteries or accumulators included from other types of waste and to arrange for disposal by the municipal waste service. It is possible to ask your local dealer to collect the waste electric or electronic appliance under the conditions and following the methods provided by national laws transposing the Directive 2012/19/EU.

Separate waste collection and recycling of unused electric and electronic equipment, batteries and accumulators helps to save natural resources and to guarantee that this waste is processed in a manner that is safe for health and the environment. For more information about how to collect electric and electronic equipment and appliances, batteries and accumulators, please contact your local Council or Public Authority competent to issue the relevant permits.







# Extraflame®

## Riscaldamento a Pellet

**EXTRAFLAME S.p.A.** Via Dell'Artigianato, 12 36030 - MONTECCHIO PRECALCINO (VI) - ITALY

☎ +39.0445.865911 - ☎ +39.0445.865912 - ☐ info@extraflame.it - ☐ www.lanordica-extraflame.com

**MADE IN ITALY**  
design & production

*TO FIND THE SERVICE CENTRE NEAREST TO YOU  
CONTACT YOUR DEALER OR CONSULT  
THE SITE [WWW.LANORDICA-EXTRAFLAME.COM](http://WWW.LANORDICA-EXTRAFLAME.COM)*

The manufacturer reserves the right to vary the characteristics and the data reported in this pamphlet at any moment and without notice, in order to improve its products.